





SCREW IN PLUNGER

Stainless Steel 316 Cover & Nylon & Rubber & PP

- Top mount design for installations where thickness limitations or solid core situations are present.
- Compact design can be used in numerous applications, including seat cushions, seat backs, small hatches, electric panels, etc.
- Enables the cushion to open fully and allows unlimited access to storage spaces.
- #0507475/6: Engagement can be adjusted by reversing or removing the spacer under catch.
- Marking punch to ensure correct alignment is sold separately.
- Screw size of #0507475/6: #8 or M4.
- Screw size of #0607477/8/9/80: #8 or M4 for female part, and 1/4" or M6 for male part.

Patented

0507475/6 CATCH HEIGHT		
Without Spacer	With Spacer	Reverse Spacer
		
11(7/16")	13.5(9/16")	16(5/8")
Tighter Engagement		
		Looser Engagement



Bulk No.	S.S. Cover	A mm	B mm	C mm	D mm	E mm	Holding Power
0507475	Without	28(1-1/8")	25.5(1")	58(2-1/4")	13.5(9/16")	12.5(1/2")	8kg(17lb)
0507476	With	28(1-1/8")	25.5(1")	60(2-3/8")	13.5(9/16")	12.5(1/2")	8kg(17lb)
0607577	Without	28(1-1/8")	25.5(1")	58(2-1/4")	13.5(9/16")	12.5(1/2")	16kg(35lb)
0607578	With	28(1-1/8")	25.5(1")	60(2-3/8")	13.5(9/16")	12.5(1/2")	16kg(35lb)
0107426-G	Marking Punch For 0507475/6, 0607577/8						
0607477	Without	50(2")	37.8(1-1/2")	82(3-1/4")	27(1-1/16")	25.4(1")	10kg(22lb)
0607478	With	50(2")	37.8(1-1/2")	83.9(3-5/16")	27(1-1/16")	25.4(1")	10kg(22lb)
0607479	Without	50(2")	37.8(1-1/2")	82(3-1/4")	27(1-1/16")	27(1-1/16")	17kg(37lb)
0607480	With	50(2")	37.8(1-1/2")	83.9(3-5/16")	27(1-1/16")	27(1-1/16")	17kg(37lb)
1007420-G	Marking Punch For 0607477/8/9/80						


INSTALLATION INSTRUCTION




Drill an installation hole.



Tighten screws.



Insert marking punch to mark for alignment.



Install male part with a fastener and hold in place.

